

WOZOYO PURE AIR PA1

Compact Air Purifier • 4-in-1 Filtration • Aromatherapy



4-in-1 Filtration	110 m³/h CADR
Pre-Filter, Nano-Silver Anti-Bacterial Filter, HEPA 13 and Activated Carbon.	Designed for the stated applicable area of 404 ft² / 38 m² at 1 ACH.

Key Highlights

- **110 m³/h CADR** for efficient air circulation.
- **4-in-1 filtration** with Pre-Filter, Nano-Silver Anti-Bacterial, HEPA 13 and Activated Carbon.
- **3 fan-speed levels** from low (1) to high (3).
- **Child Lock** disables all buttons when activated.
- **2 / 4 / 8-hour timer** for convenient operation.
- **Aromatherapy compartment** with 4 supplied aromatherapy pads.
- **Light control** and dedicated filter-reset function.

Specifications at a Glance

Model	Pure Air PA1
Adapter Input	100–240 V~, 50/60 Hz
Adapter Output	12 V = 1 A
Rated Power	12 W
Noise – High Speed	45 dB/A
Noise – Low Speed	22 dB/A
CADR	110 m³/h
Applicable Area (1 ACH)	404 ft² / 38 m²
Net Weight	1.07 kg
Dimensions	170 × 160 × 262 mm

4-Stage Filtration

1	Pre-Filter	First filtration stage for larger particles.
2	Nano-Silver Anti-Bacterial Filter	Anti-bacterial filtration stage specified by the manufacturer.
3	HEPA 13 Filter	High-efficiency particulate filtration stage.
4	Activated Carbon Filter	Helps with odours and certain gaseous pollutants.

The supplied manual identifies the PA1 as using a 4-in-1 compound filter.

Simple Controls & Aromatherapy

The PA1 provides controls for power, fan speed, child lock, timer, filter reset and light.

Power	Connect the supplied power adapter. Press Power to turn the purifier on; press again to enter standby.
Fan Speed	Press Fan Speed to select one of three levels: low (1) to high (3).
Child Lock	Press the Child Lock button for 3 seconds to enter or exit Child Lock. All buttons are disabled while active.
Timer	Set the timer for 2, 4 or 8 hours.
Filter Reset	When the filter indicator blinks, replace the filter and press Filter Reset for 3 seconds.
Light	Short press to turn the light on or off.

How to Use Aromatherapy

- Press the **PUSH** compartment at the back of the purifier to release the aromatherapy tray.
- Remove the tray to access the aromatherapy pad.
- Add a few drops of essential oil or equivalent fragrance to the pad.
- Insert the tray back into the unit.
- **Note:** Essential oils/fragrances are not included. The PA1 package includes 4 aromatherapy pads.

Care, Maintenance & Troubleshooting

Cleaning

- Switch off and unplug before cleaning.
- Wipe with a soft, clean cloth; if needed, use a clean damp cloth and dry immediately.
- Do not use alcohol, oil or benzene.
- Do not immerse the unit in water.
- Clean the 4-in-1 compound filter with a dry, soft cloth.

Filter Replacement

Replacement frequency depends on usage and air quality. After replacing the filter, press the Filter button for 3 seconds to reset the filter indicator.

Quick Troubleshooting

Problem	Check / Action
Unit will not turn on / buttons do not respond	Check that the power cord is connected securely. Make sure the purifier is stable and check whether Child Lock is active.
Unusual / foul smell	Change the purifier's placement and position. Keep 20 cm clearance on all sides and check whether filters are dirty or need replacement.
Air quality does not improve	Clean or replace the filters, confirm the protective plastic bag was removed, and make sure the filters are installed correctly.

What's Included

- PA1 Air Purifier — 1 unit
- 4-in-1 Compound Filter — 1 unit
- Thank You Card — 1 unit
- Aromatherapy Pads — 4 units
- Power Adapter — 1 unit

Important

Use only the supplied power adapter and specified replacement filter. Do not block the air inlet or outlet. Keep the purifier indoors and maintain more than 20 cm clearance from the wall.

WOZOYO • Inspired Innovation