

WOZOYO PURE AIR PA2

Compact Air Purifier • 4-in-1 Filtration • Easy Operation



4-in-1 Filtration	165 m³/h CADR
Pre-Filter, Nano-Silver Anti-Bacterial Filter, HEPA 13 and Activated Carbon.	Designed for the stated applicable area of 673 ft² / 63 m² at 1 ACH.

Key Highlights

- **165 m³/h CADR** for efficient air circulation.
- **4-in-1 filtration** with Pre-Filter, Nano-Silver Anti-Bacterial, HEPA 13 and Activated Carbon.
- **3 fan-speed levels** from low (1) to high (3).
- **Sleep Mode** runs at the lowest fan speed with reduced panel lighting.
- **1 / 2 / 4 / 8-hour timer** for convenient operation.
- **Light control** and filter-reset function.

Specifications at a Glance

Model	Pure Air PA2
Adapter Input	100–240 V~, 50/60 Hz
Adapter Output	12 V = 1.5 A
Rated Power	18 W
Noise – High Speed	50 dB/A
Noise – Low Speed	22 dB/A
CADR	165 m³/h
Applicable Area (1 ACH)	673 ft² / 63 m²
Net Weight	1.9 kg
Dimensions	205 × 205 × 312 mm

4-Stage Filtration

1	Pre-Filter	First filtration stage for larger particles.
2	Nano-Silver Anti-Bacterial Filter	Anti-bacterial filtration stage specified by the manufacturer.
3	HEPA 13 Filter	High-efficiency particulate filtration stage.
4	Activated Carbon Filter	Helps with odours and certain gaseous pollutants.

The supplied manual identifies the PA2 as using a 4-in-1 compound filter.

Simple Controls. Easy Operation.

The PA2 provides controls for power, fan speed, Sleep Mode, timer, light and filter reset.

Power	Connect the supplied power adapter. Press Power to turn the purifier on; press again to enter standby.
Fan Speed	Press the Fan Speed button to select one of three levels: low (1) to high (3).
Sleep Mode	Use the Fan Speed button to toggle to Sleep Mode. The purifier runs at the lowest fan speed and the panel lights turn off except the Sleep indicator.
Timer	Set the timer for 1, 2, 4 or 8 hours.
Light	Short press to turn the light on or off.
Filter Reset	After replacing the filter, press the Light button for 3 seconds to reset the filter indicator.

Filter Installation

- Rotate the bottom panel counterclockwise and remove it.
- Take the filter and power adapter out of the purifier.
- Remove the protective PE bag from the filter and re-insert the filter.
- Rotate the bottom panel clockwise to secure it.

Care, Maintenance & Troubleshooting

Cleaning

- Switch off and unplug before cleaning.
- Wipe with a soft, clean cloth; if needed, use a clean damp cloth and dry immediately.
- Do not use alcohol, oil or benzene.
- Do not immerse the unit in water.
- Clean the 3-in-1 compound filter with a dry, soft cloth.

Filter Replacement

Replacement frequency depends on usage and air quality. After replacing the filter, press the Light button for 3 seconds to reset the filter indicator.

Quick Troubleshooting

Problem	Check / Action
Unit will not turn on / buttons do not respond	Place the purifier securely on the ground and check whether Child Lock is active. If the Child Lock icon is on, deactivate Child Lock.
Unusual / foul smell	Change the purifier's placement and position. Keep 20 cm clearance on all sides and check whether filters are dirty or need replacement.
Air quality does not improve	Clean or replace the filters, confirm the protective plastic bag was removed, and make sure the filters are installed correctly.

What's Included

- PA2 Air Purifier — 1 unit
- 4-in-1 Compound Filter — 1 unit
- Thank You Card — 1 unit
- Power Adapter — 1 unit

Important

Use only the supplied power adapter and specified replacement filter. Do not block the air inlet or outlet. Keep the purifier indoors and maintain more than 20 cm clearance from the wall.

WOZOYO • Inspired Innovation