

AIR TOUCH P2

PLATINUM SERIES



AIR TOUCH ADVANTAGE

- Real time PM2.5 level display
- CADR of up to 550 m³/h¹
- Coverage area of up to 853 square feet²
- Advanced filtration system with 5 air purification cycle per hour
- Pre-Filter, Anti-Bacterial Filter & High grade H13 HEPA filter
- Activated Carbon filter
- Equipped with UV LED to help kill harmful bacteria³
- Wi-Fi function enabled with "Honeywell Air Touch" App
- Silent operation with noise level of 53db/A at high speed
- 4 Air purifying speeds along with Auto Mode
- Sleep mode with 1, 2, 4 or 8 hour automatic shut-off timer
- Child Lock button
- Filter Reset Indicator
- Filter life of up to 3000 hours or 1 Year⁴
- 1 Year on-site Warranty
- Power consumption: 50W
- Power Voltage : 220-240V/50-60Hz
- 3D Airflow⁴

1. For the air that passes through the filter. Purification performance parameters are tested under specific third-party laboratory conditions with specific dust particles and formaldehyde gas as target pollutants. Overall particle reduction depends on many factors including the amount of air processed, the pollutant type and the pollutant introduction rate into the environment.

2. Air Purifier Ratings (H13) Air Purifier CADR Rating Scale (Convert Sq Ft Room to CADR) (online) Available at <https://air-purifier-ratings.org/learn/cadr-ratings-scale/>

3. Guangdong Detection Center of Microbiology Report No. 2020FUDQ294R02E, March 15, 2020. Results: Escherichia coli: 99.99%, Staphylococcus aureus: 99.99%, Candida albicans: 99.99%. The UV LED is effective inside the Air Purifier.

4. 3D circulation airflow is divided into two modes, including Front Airflow and Upwards Airflow. Usually, various types of dirt appear at different positions between the ceiling and the floor in the room, and they can be purified by different modes of 3D airflow respectively. Front Airflow mode cleans up house dusts appearing within 30cm above the floor, while Upwards Airflow removes dusts floating in the air.

TECHNICAL DETAILS

PRODUCT NAME: AIR TOUCH P2	
Rated Voltage	220-240V
Rated Frequency	50/60Hz
Rated Power	50W
Noise (High Speed)	53dB/A
Noise (Low Speed)	23dB/A
Amount of Particulate Cleaned Air (CADR) ¹	550m ³ /h
Amount of Formaldehyde Cleaned Air (CADR) ¹	82.9m ³ /h
Applicable Area ²	853 square feet
Suggested Period to Replace Filters ³	3 in 1 Compound Filter life up to 3000 hours or 1 year
Net Weight	5.5kg
Product Measurements	L260xW263xH524mm
Components	3 in 1 Compound Filter



3 COLOR
AIR QUALITY
INDICATOR



QUIET
OPERATION



LOW POWER
CONSUMPTION



H13 HEPA
FILTER



AIR CHANGE
PER HOUR



IDEAL ROOM
SIZE



FILTER RESET
INDICATOR



CADR
550 m³/h



4 FAN SPEED



SLEEP MODE



TIMER



FILTER LIFE



Wi-Fi



UV



Honeywell