

AIR TOUCH U2

ULTIMATE SERIES



AIR TOUCH ADVANTAGE

- Real time PM2.5 level display
- CADR of up to 650 m³/h¹
- Coverage area of up to 1008 square feet²
- Advanced filtration system with 5 air purification cycle per hour
- Pre-Filter, Anti-Bacterial Filter & High grade H13 HEPA filter
- Cold Catalyst & Activated Carbon filter
- Equipped with UV LED and Ionizer to help kill harmful bacteria³
- Equipped with Humidifier to maintain ideal moisture levels in ambient air
- Wi-Fi function enabled with “Honeywell Air Touch” App
- Silent operation with noise level of 59db/A at high speed
- 8 Air purifying speeds along with Auto mode
- Child lock button
- Sleep mode with 1-12 hour automatic shut-off timer
- Equipped with Remote Control for convenient use
- Filter Reset Indicator
- Filter life of up to 3000 hours or 1 Year¹
- 1 Year on-site Warranty
- Power consumption: 85W
- Power Voltage : 220-240V/50~60Hz
- 3D Airflow⁴

1. For the air that passes through the filter, Purification performance parameters are tested under specific third-party laboratory conditions with specific dust particles and formaldehyde gas as target pollutants. Overall particle reduction depends on many factors including the amount of air processed, the pollutant type and the pollutant introduction rate into the environment.

2. Air Purifier Ratings. (n.d.). Air Purifier CADR Ratings Scale | Convert Sq Ft Room to CADR. [online] Available at: <https://air-purifier-ratings.org/learn/cadr-ratings-scale/>.

3. Guangdong Detection Center of Microbiology, Report No 2020FM04294R01E, March 15, 2020. Results: Escherichia Coli: 99.99%, Staphylococcus Aureus: 99.99%, Candida Albicans: 99.99%. The UV LED is effective inside the Air Purifier.

4. 3D circulation airflow is divided into two modes, including Front Airflow and Upwards Airflow. Usually, various types of dirt appears at different positions between the ceiling and the floor in the room, and they can be purified by different modes of 3D airflow respectively. Front Airflow mode cleans up house dust spreading within 30cm above the floor, while Upwards airflow removes odor floating in the air.

TECHNICAL DETAILS

PRODUCT NAME: AIR TOUCH U2	
Rated Voltage	220-240V
Rated Frequency	50/60Hz
Rated Power	85W
Noise (High Speed)	59dB/A
Noise (Low Speed)	38.0dB A
Anion Concentration	10million/cm³
Amount of Particulate Cleaned Air (CADR) ¹	650m³/h
Amount of Formaldehyde Cleaned Air (CADR) ¹	101.6m³/h
Applicable Area ²	1008 square feet
Suggested Period to Replace Filters	• Pre-Filter life up to 2 years • Compound Anti-Bacterial + H13 HEPA Filter life up to 3000 hours or 1 year • Compound Cold Catalyst + Carbon Filter life up to 3000 hours or 1 year
Net Weight	11.3kg
Product Measurements	400x230x640mm
Components	Pre-Filter, Compound Anti-Bacterial + H13 HEPA Filter, Compound Cold Catalyst + Carbon Filter and Humidifier Filter



Honeywell