

WOZOYO PURE AIR PA5

Compact Air Purifier • 4-in-1 Filtration • Wi-Fi Enabled



4-in-1 Filtration	450 m³/h CADR
Pre-Filter, Nano-Silver Anti-Bacterial Filter, H13 HEPA and Activated Carbon.	Efficient air circulation for the stated applicable area.

Key Highlights

- **450 m³/h CADR** for effective air circulation.
- **H13 HEPA filtration** with Nano-Silver Anti-Bacterial, Pre-Filter and Activated Carbon stages.
- **Auto Mode** adjusts fan speed according to current air quality.
- **Sleep Mode** operates at the lowest fan speed.
- **1 / 2 / 4 / 8-hour timer** for convenient operation.
- **Wi-Fi control** through the Wozoyo Purify app.
- **Child Lock** helps prevent unintended button operation.

Specifications at a Glance

Model	Pure Air PA5
Rated Voltage	120 V
Rated Frequency	60 Hz
Rated Power	45 W
Noise – High Speed	54 dB/A
Noise – Low Speed	22 dB/A
CADR	450 m³/h
Applicable Area (1 ACH)	1570 ft² / 146 m²
Net Weight	4.0 kg
Dimensions	L240 × W240 × H470 mm

4-Stage Filtration

1	Pre-Filter	Helps capture larger particles before the main filtration stages.
2	Nano-Silver Anti-Bacterial Filter	Anti-bacterial filtration stage specified in the supplied manual.
3	H13 HEPA Filter	High-efficiency particulate filtration stage.
4	Activated Carbon Filter	Helps with odour and certain gaseous pollutants.

The supplied manual identifies this as a 4-in-1 compound filter.

Simple Controls. Smart Operation.

The PA5 provides controls for power, timer, fan speed, Auto Mode, Sleep Mode, Wi-Fi, filter reset and child lock.

Power	Turns the air purifier on or off.
Timer	Set operation for 1, 2, 4 or 8 hours.
Fan Speed	Choose low, medium or high. Brightness can be adjusted by holding the Mode button for 3 seconds.
Auto Mode	Automatically changes fan speed according to current air quality.
Sleep Mode	Operates at the lowest fan speed; the control-panel lights can be turned off.
Wi-Fi	Press the Wi-Fi buttons simultaneously for 3 seconds to enter Wi-Fi configuration.
Filter Reset	When the filter indicator flashes, replace the filter and press Filter Reset for 3 seconds.
Child Lock	Press Auto for 3 seconds to enter or exit Child Lock. Buttons are disabled while active.

Wi-Fi Connection

- Download the **Wozoyo Purify** app from the Apple App Store or Google Play Store.
- Turn on the purifier and press the **Wi-Fi button for 3 seconds**.
- Open the app, go to the home page and select **Add Device**.
- Follow the app instructions to complete connection.
- The Wi-Fi indicator blinks during configuration and stays on after successful connection.

Care, Maintenance & Troubleshooting

Cleaning

- Switch off and unplug before cleaning.
- Wipe with a soft, clean cloth; if needed, use a clean damp cloth and dry immediately.
- Do not use alcohol, oil or benzene.
- Do not immerse the unit in water.
- Clean the 3-in-1 filter with a dry, soft cloth.

Filter Replacement

Replacement frequency depends on usage and air quality. After replacing the filter, press the Timer button for 3 seconds to reset the filter indicator.

Quick Troubleshooting

Problem	Check / Action
Unit will not turn on	Check the power cord, wall socket, purifier stability and whether Child Lock is active.
Air quality does not improve	Change the purifier's position, keep at least 20 cm clearance around it, and check whether filters are dirty or need replacement.
PM2.5 light stays red	Check filter condition and placement. Replace filters if necessary and confirm the protective plastic bag was removed.
Unusual smell	Check filter condition and make sure the filters are installed correctly.

Error Codes

E1	Filter removed; display shows E1 and the device cannot be powered on.
E2	Motor malfunction; display shows an E2 error.
E3	Particle sensor fault; display shows an E3 error.

Important

Use only the recommended replacement filter. Do not block the air inlet or outlet. Follow the supplied manual for safe operation.

WOZOYO • Inspired Innovation