

WOZOYO PURE AIR PA6

Smart Air Purifier • Clear air-quality information • Wi-Fi enabled



4-in-1 Filtration	Real-time Monitoring
Pre-Filter, Nano-Silver Anti-Bacterial Filter, H13 True HEPA and Activated Carbon.	Displays PM2.5, TVOC, temperature and humidity information.

Key Highlights

- **700 m³/h CADR** for efficient air circulation.
- **H13 True HEPA filtration** with activated carbon and pre-filtration.
- **PM2.5 & TVOC monitoring** with a colour air-quality indicator.
- **Auto, Sleep and Turbo modes** for different operating needs.
- **1 / 2 / 4 / 8-hour timer** and child-lock function.
- **Wi-Fi connectivity** through the Wozoyo Purify app.

Specifications at a Glance

Model	Pure Air PA6
Rated Voltage	120 V
Rated Frequency	60 Hz
Rated Power	70 W
Noise – High Speed	59 dB/A
Noise – Low Speed	22 dB/A
CADR	700 m³/h
Applicable Area	Approx. 2915 ft² / 271 m² (1 ACH)*
Net Weight	9.8 kg
Dimensions	L320 × W320 × H745 mm

4-Stage Filtration

1	Pre-Filter	Helps capture larger particles before the main filtration stages.
2	Nano-Silver Anti-Bacterial Filter	Anti-bacterial filtration stage specified by the manufacturer.
3	H13 True HEPA Filter	High-efficiency particulate filtration stage.
4	Activated Carbon Filter	Helps reduce odours and certain gaseous pollutants.

*Applicable area is stated in the original manufacturer brochure at 1 air change per hour (1 ACH).

Simple Controls. Smart Monitoring.

The display shows temperature & humidity, PM2.5 and TVOC readings. The PM2.5/TVOC colour indicator changes according to the measured air-quality level.

Power	Turns the air purifier on or off.
Mode	Auto adjusts fan speed to current air quality. Sleep uses the lowest fan speed. Turbo uses high-speed purification. Brightness can also be adjusted.
Timer	Set operation for 1, 2, 4 or 8 hours.
Fan Speed	Choose among three fan-speed levels: low, medium and high.
Child Lock	Press Power + Speed for 3 seconds to lock or unlock the controls.

Wi-Fi Connection

- Download the **Wozoyo Purify** app from the Apple App Store or Google Play Store.
- Turn on the purifier and press **Mode + Timer** together for 3 seconds until Wi-Fi configuration starts.
- Open the app, select **Add Device**, and follow the connection steps.
- The Wi-Fi indicator remains on when the connection is successful.

What's Included

- WOZOYO Pure Air PA6 Air Purifier — 1 unit
- 4-in-1 filter — 1 unit
- Thank You Card — 1 unit

Care, Maintenance & Quick Troubleshooting

Cleaning

- Switch off and unplug the purifier before cleaning.
- Wipe the unit with a soft, clean cloth. If needed, use a damp cloth only.
- Do not use alcohol, benzene or other chemicals.
- Do not immerse the unit in water.
- Wipe the 3-in-1 compound filter with a dry, soft cloth.

Filter Replacement

Filter replacement frequency depends on usage and air quality. After replacing the filter, press and hold the Timer button for 3 seconds to reset the filter indicator.

Quick Checks

Problem	Check / Action
Unit will not turn on	Check the power connection, wall socket, back panel and whether Child Lock is active.
Air quality does not improve	Ensure at least 20 cm clearance around the purifier. Check whether filters are dirty or installed correctly.
PM2.5 light stays red	Check the filter condition and placement. Replace the filter if necessary.
Airflow smells unusual	Check the filters and confirm that the protective plastic packaging was removed before installation.

Error Codes

E1: Filter removed / filter-related protection.

E2: Motor malfunction.

E3: Particle sensor fault.

Important

For safe operation, follow the manufacturer's instructions and use only the specified replacement filter. Do not block the air inlet or outlet.

WOZOYO • Inspired Innovation